

AquaTrough



AquaTrough

5' Water Trough

The Water Trough Assembly is used when the extrusion application requires the extrudate to be quenched prior to pelletizing. The 5" width x 5" depth bath unit can accommodate either single or multiple rod strands. It is mounted on a heavy duty mobile cart, with adjustable height floor stand. Provided with an inlet and outlet for quick and easy filling of water, or for continuous circulation during the extrusion process.

Options:

- Air Knife Assembly, can be mounted to the trough for removal of water prior to entering the pelletizer
 - Water Circulator
 - Tubing Accessory Package: including tube guide plate assembly and drip pans
-